



Push-in Seal Instructions

Gently pull out the existing seal being careful not to damage the PVC seal retainer, especially at the corners.

Support the new seal in its correct shape to ensure it does not get damaged, starting at the top, position the seal's arrow head in the door's seal-retainer cavity and apply pressure with the palm of your hand or thumb. You may need to manipulate the seal while applying pressure and/or use both thumbs. Be careful not to stretch the seal as you fit it!

Only complete across the top and partially down the sides approximately 100mm, then start at the bottom working your way back up the sides. This is to avoid over-stretching the seal.

Check that the seal is pushed in correctly all the way around before shutting the door.

When shutting the door for the first time, ensure that the seal is not going to catch on the cabinet and get damaged, by watching the hinge side close from the outside of the door.

Sometimes these seals require mild heat with a hair drier when the door is closed to soften the PVC and allow the magnetic strip to extend the seal concertina. After heating the seals do not open the door until the seal has cooled down (approximately 10 minutes).